



Presentation Summary

- VAI "History"
- EPA's VAI Homeowner Information Strategy Overview
- How do I know whether I have Libby Vermiculite?
- Preliminary Decisions in the Method developed in Covington, KY
- VAI Program Future









VAI "History"

- Libby, MT health problems
- Libby vermiculite in products may be a problem
- Large amounts of vermiculite in attic insulation
- Estimates of millions of homes with VAI
- NPCD Vermont Study of 6 houses and simulation chamber studies
- EPA/ATSDR Pamphlet on VAI









EPA's VAI Homeowner Information Strategy

- Pamphlet Do not disturb (completed)
- How do I know whether I have Libby VAI?
- What is the potential hazard from my VAI?
- What happens if I have to disturb my VAI?
- What are my options for VAI removal/disposal?









How do I know whether I have Libby Vermiculite?

- Qualitative identification (Covington Meeting)
- Semi-quantitative method evaluation (weight percent of solids, not asbestos)
- Method verification and validation
- Preparation of standards/reference materials









Preliminary Decisions in the Method developed in Covington, KY



DRAFT September 4, 2003

Method for Sampling and Analysis of Fibrous Amphibole in Vermiculite Attic Insulation

Prepared for:

Mr. Roger C. Wilmoth and Mr. Glenn M. Shaul U.S. Environmental Protection Agency 26 West Martin Luther King Drive Cincinnati, OH 45268

Developed from input received at an interagency meeting on
"Analytical Method for Bulk Analysis of Vermiculite"

Marriott Courtyard Hotel

Covington, Kentucky

July 17-18, 2003


Prepared by:
Michael E. Beard
RTI International
3040 Cornwallis Road
Research Triangle Park, NC 27709-2194













Analyze "Sinks"

- Dry the solids ("sinks") which sank in the flotation process
- Dry the sinks and examine for amphibole using a stereo optical microscope
- Manually separate amphibole pieces from other pieces in the sinks
- Weigh amphibole pieces to determine weight percent of amphibole in VAI









Analyze "Sinks" (cont.)

- Select an amphibole piece and tease out individual fibers for PLM analysis
- Prepare a slide for PLM examination and add high dispersion liquid having a refractive index of 1.630
- If there are no Libby amphibole sinks (based on the refractive index), analyze the water









Analyze "Liquids"

- Homogenize the water and remove an aliquot for drying and analysis
- Prepare the dried suspended solids (fines) for SEM/TEM analysis
- Analyze the fines for Libby amphibole
- It there are no Libby amphibole particles in the fines, analyze the floats









Analyze "Floats"

- Add the floats back to water and agitate/ sonicate?
- Repeat the analytical process starting at the first VAI flotation step and examine and new sinks and second decantate of water.









VAI Program Future –

What is the potential hazard from my VAI?

- Start from a semi-quantitative surrogate method
- Compare the surrogate method results with air sampling results
- Method verification and validation
- Preparation of standards/reference materials









Presentation Review

- VAI "History"
- EPA's VAI Homeowner Information Strategy Overview
- How do I know whether I have Libby Vermiculite?
- Preliminary Decisions in the Method developed in Covington, KY
- VAI Program Future





